

# **IH 2055/2090/2013**

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Alat ganti**

**Reservdelar**

Replaces

Ersetzt

Remplace

Vervangt

Reemplaza


Menggantikannya

Ersätter


**106 25 14-71**

From serial number: 1501001-1502015


# A




compl 501 39 79-03




compl 531 00 00-01



**B**




C



# C1


**\*\*Compl 5310197-64**




\*5310193-23-**9687435, 9687436, 9687445, 9687446, 9687448**

\*5310193-24-**9687437**


**D**




E




F



# F1




G



**Driver Pulley :**


**5310138-83**



| Parts | Description           | Qty      | 0600-0021            |
|-------|-----------------------|----------|----------------------|
|       | <b>Driver pulley</b>  | <b>1</b> | <b>5310138-83</b>    |
| 1     | Fixed flange          | 1        | 5310138-83-1         |
| 2     | Sliding flange        | 1        | 5310138-83-2         |
| 3     | Slider washer         | 1        | 5310138-83-3         |
| 4     | Spring guide washer   | 1        | 5310138-83-4         |
| 5     | Spring                | 1        | 5310138-83-5         |
| 6     | <b>Stroke limiter</b> | 1        | <b>5310138-83-6</b>  |
|       |                       |          |                      |
| 8     | Spring cover          | 1        | 5310138-83-8         |
| 9     | Internal snap ring    | 1        | 5310138-83-9         |
|       |                       |          |                      |
| 11    | <b>Cap</b>            | 1        | <b>5310138-83-11</b> |
| 12    | Lock washer           | 1        | 5310138-83-12        |
| 13    | Lock Nut              | 1        | 5310138-83-13        |
| 14    | Block                 | 3        | 5310138-83-14        |
| 15    | <b>275 gr Weight</b>  | 3        | <b>5310138-83-15</b> |


**Driven Pulley :**

**5310138-84**



| Parts | Description           | Qty      |                   |
|-------|-----------------------|----------|-------------------|
|       | <b>Driven pulley</b>  | <b>1</b> | <b>5310138-84</b> |
| 1     | Fixed Flange          | 1        | 5310138-84-1      |
|       |                       |          |                   |
| 3     | Sliding Flange        | 1        | 5310138-84-3      |
| 4     | Spring                | 1        | 5310138-84-4      |
| 5     | Cam                   | 1        | 5310138-84-5      |
| 6     | <b>Square key 1/2</b> | 1        | 5310138-84-6      |
| 7     | Snap Ring             | 1        | 5310138-84-7      |
| 8     | Cam Shoe              | 3        | 5310138-84-8      |
|       | <b>Belt</b>           | <b>1</b> | <b>5310138-85</b> |

\*compl 531 00 14-81



| PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE |
|--------------|-------------|--------------|-------------|--------------|-------------|--------------|-------------|
| 501 39 79-03 | A           | 531 00 01-91 | E           | 531 00 10-73 | H           | 531 01 20-83 | H           |
| 501 39 94-01 | C           | 531 00 01-92 | E           | 531 00 10-75 | H           | 531 01 20-84 | G           |
| 531 00 00-01 | A           | 531 00 01-93 | E           | 531 00 10-76 | H           | 531 01 20-85 | H           |
| 531 00 00-02 | A           | 531 00 01-94 | AEH         | 531 00 10-77 | H           | 531 01 20-94 | F           |
| 531 00 00-04 | A           | 531 00 01-95 | A           | 531 00 10-78 | H           | 531 01 20-95 | F           |
| 531 00 00-05 | A           | 531 00 02-27 | F           | 531 00 10-80 | H           | 531 01 21-02 | H           |
| 531 00 00-06 | A           | 531 00 02-45 | H           | 531 00 10-81 | H           | 531 01 21-03 | H           |
| 531 00 00-13 | AE          | 531 00 02-51 | H           | 531 00 10-82 | H           | 531 01 21-04 | H           |
| 531 00 00-14 | E           | 531 00 02-52 | H           | 531 00 10-83 | H           | 531 01 21-08 | H           |
| 531 00 00-15 | A           | 531 00 02-55 | C           | 531 00 10-84 | H           | 531 01 21-09 | H           |
| 531 00 00-16 | A           | 531 01 02-98 | F           | 531 00 10-85 | CH          | 531 01 21-23 | A           |
| 531 00 00-17 | AG          | 531 00 03-26 | C           | 531 00 10-86 | H           | 531 01 21-76 | F           |
| 531 00 00-19 | A           | 531 00 03-27 | C           | 531 00 10-87 | H           | 531 01 92-79 | F           |
| 531 00 00-20 | A           | 531 00 03-28 | C           | 531 00 10-88 | H           | 531 01 92-92 | H           |
| 531 00 00-22 | A           | 531 00 03-30 | C           | 531 00 10-90 | H           | 531 01 93-00 | A           |
| 531 00 00-76 | D           | 531 00 03-33 | C           | 531 00 11-07 | E           | 531 01 93-01 | C           |
| 531 00 00-80 | DH          | 531 00 03-35 | C           | 531 00 11-08 | E           | 531 01 93-02 | C           |
| 531 00 00-82 | D           | 531 00 03-36 | C           | 531 00 11-12 | H           | 531 01 93-03 | C           |
| 531 00 00-83 | D           | 531 00 03-37 | C           | 531 00 11-13 | H           | 531 01 93-04 | D           |
| 531 00 00-84 | D           | 531 00 03-38 | C           | 531 00 11-18 | H           | 531 01 93-13 | D           |
| 531 00 00-85 | D           | 531 00 03-40 | C           | 531 00 11-19 | H           | 531 01 93-17 | C           |
| 531 00 00-86 | D           | 531 00 03-42 | C           | 531 00 11-22 | H           | 531 01 93-18 | D           |
| 531 00 00-87 | D           | 531 00 03-44 | A           | 531 00 11-24 | H           | 531 01 93-19 | C           |
| 531 00 00-88 | D           | 531 00 03-45 | C           | 531 00 14-03 | C           | 531 01 93-20 | C           |
| 531 00 00-89 | D           | 531 00 03-46 | C           | 531 00 14-05 | D           | 531 01 93-21 | C           |
| 531 00 00-90 | DH          | 531 00 04-24 | H           | 531 00 14-11 | F           | 531 01 93-22 | C           |
| 531 00 00-91 | D           | 531 00 09-25 | A           | 531 00 14-16 | F           | 531 01 93-23 | C           |
| 531 00 00-92 | D           | 531 00 09-73 | D           | 531 00 14-29 | F           | 531 01 93-24 | C           |
| 531 00 00-93 | D           | 531 00 09-74 | D           | 531 00 14-81 | H           | 531 01 93-26 | C           |
| 531 00 00-94 | D           | 531 00 09-94 | F           | 531 00 14-86 | A           | 531 01 93-27 | D           |
| 531 00 00-97 | D           | 531 00 09-99 | H           | 531 00 14-87 | A           | 531 01 93-40 | C           |
| 531 00 01-01 | D           | 531 00 10-02 | H           | 531 00 14-88 | A           | 531 01 93-46 | D           |
| 531 00 01-03 | D           | 531 00 10-11 | A           | 531 00 14-90 | A           | 531 01 93-47 | D           |
| 531 00 01-05 | D           | 531 00 10-12 | H           | 531 00 14-93 | A           | 531 01 93-48 | D           |
| 531 00 01-06 | D           | 531 00 10-16 | H           | 531 00 15-63 | A           | 531 01 93-54 | G           |
| 531 00 01-07 | D           | 531 00 10-18 | H           | 531 00 16-95 | G           | 531 01 93-55 | G           |
| 531 00 01-08 | D           | 531 00 10-20 | H           | 531 00 16-99 | G           | 531 01 93-70 | DF          |
| 531 00 01-12 | H           | 531 00 10-24 | H           | 531 00 17-62 | G           | 531 01 94-82 | G           |
| 531 00 01-15 | D           | 531 00 10-27 | F           | 531 00 17-63 | G           | 531 01 95-04 | B           |
| 531 00 01-16 | D           | 531 00 10-29 | H           | 531 00 17-64 | G           | 531 01 95-06 | B           |
| 531 00 01-17 | D           | 531 00 10-30 | AF          | 531 00 18-26 | C           | 531 01 95-09 | D           |
| 531 00 01-20 | D           | 531 00 10-41 | H           | 531 00 18-28 | C           | 531 01 95-19 | B           |
| 531 00 01-22 | D           | 531 00 10-43 | H           | 531 00 18-83 | C           | 531 01 95-21 | B           |
| 531 00 01-24 | D           | 531 00 10-44 | H           | 531 00 18-84 | C           | 531 01 95-22 | B           |
| 531 00 01-28 | GH          | 531 00 10-45 | H           | 531 01 19-16 | A           | 531 01 95-24 | AB          |
| 531 00 01-29 | D           | 531 00 10-46 | CH          | 531 01 19-19 | A           | 531 01 95-42 | H           |
| 531 00 01-30 | D           | 531 00 10-47 | H           | 531 01 19-22 | A           | 531 01 95-84 | B           |
| 531 00 01-31 | D           | 531 00 10-48 | H           | 531 01 19-80 | G           | 531 01 95-85 | B           |
| 531 00 01-36 | D           | 531 00 10-49 | H           | 531 01 19-81 | D           | 531 01 95-90 | A           |
| 531 00 01-42 | D           | 531 00 10-50 | H           | 531 01 19-82 | DG          | 531 01 96-09 | E           |
| 531 00 01-43 | D           | 531 00 10-51 | H           | 531 01 19-86 | C           | 531 01 96-10 | F           |
| 531 00 01-44 | D           | 531 00 10-52 | H           | 531 01 20-17 | F           | 531 01 96-11 | F           |
| 531 00 01-47 | G           | 531 00 10-54 | H           | 531 01 20-18 | F           | 531 01 96-12 | F           |
| 531 00 01-49 | G           | 531 00 10-55 | H           | 531 01 20-19 | G           | 531 01 96-13 | F           |
| 531 00 01-50 | G           | 531 00 10-56 | H           | 531 01 20-20 | G           | 531 01 96-14 | F           |
| 531 00 01-51 | G           | 531 00 10-57 | H           | 531 01 20-21 | G           | 531 01 96-15 | F           |
| 531 00 01-52 | G           | 531 00 10-58 | H           | 531 01 20-23 | G           | 531 01 96-16 | F           |
| 531 00 01-55 | G           | 531 00 10-59 | H           | 531 01 20-24 | G           | 531 01 96-17 | F           |
| 531 00 01-59 | G           | 531 00 10-60 | H           | 531 01 20-26 | G           | 531 01 96-18 | F           |
| 531 00 01-65 | G           | 531 00 10-61 | H           | 531 01 20-27 | G           | 531 01 96-19 | F           |
| 531 00 01-66 | G           | 531 00 10-63 | H           | 531 01 20-28 | H           | 531 01 96-20 | F           |
| 531 00 01-68 | G           | 531 00 10-64 | H           | 531 01 20-30 | D           | 531 01 96-21 | F           |
| 531 00 01-69 | G           | 531 00 10-65 | H           | 531 01 20-31 | D           | 531 01 96-23 | E           |
| 531 00 01-75 | E           | 531 00 10-66 | H           | 531 01 20-32 | H           | 531 01 96-25 | F           |
| 531 00 01-76 | E           | 531 00 10-67 | H           | 531 01 20-36 | H           | 531 01 96-27 | F           |
| 531 00 01-77 | E           | 531 00 10-68 | H           | 531 01 20-41 | F           | 531 01 96-28 | F           |
| 531 00 01-78 | EFH         | 531 00 10-69 | H           | 531 01 20-68 | A           | 531 01 96-29 | F           |
| 531 00 01-81 | E           | 531 00 10-70 | H           | 531 01 20-70 | G           | 531 01 96-31 | A           |
| 531 00 01-88 | E           | 531 00 10-71 | H           | 531 01 20-75 | D           | 531 01 96-32 | A           |
| 531 00 01-89 | E           | 531 00 10-72 | H           | 531 01 20-82 | D           | 531 01 96-35 | E           |

N = New part  
Neues teil  
Nouvelle piece  
Nueva pieza  
Ny detalj

| PART NUMBER  | SQUARE NOTE | PART NUMBER | SQUARE NOTE | PART NUMBER | SQUARE NOTE | PART NUMBER | SQUARE NOTE |
|--------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| 531 01 96-42 | A           |             |             |             |             |             |             |
| 531 01 96-43 | D           |             |             |             |             |             |             |
| 531 01 97-49 | A           |             |             |             |             |             |             |
| 531 01 97-57 | EF          |             |             |             |             |             |             |
| 531 01 97-61 | F           |             |             |             |             |             |             |
| 531 01 97-64 | C           |             |             |             |             |             |             |
| 531 01 97-65 | C           |             |             |             |             |             |             |
| 531 01 97-68 | C           |             |             |             |             |             |             |
| 531 01 97-73 | H           |             |             |             |             |             |             |
| 531 01 97-95 | H           |             |             |             |             |             |             |
| 531 01 98-31 | H           |             |             |             |             |             |             |
| 531 01 98-34 | A           |             |             |             |             |             |             |
| 531 01 98-57 | F           |             |             |             |             |             |             |
| 531 01 98-58 | F           |             |             |             |             |             |             |
| 531 01 98-59 | A           |             |             |             |             |             |             |
| 531 01 98-60 | H           |             |             |             |             |             |             |
| 531 01 98-61 | H           |             |             |             |             |             |             |
| 531 01 98-62 | H           |             |             |             |             |             |             |
| 531 01 98-65 | F           |             |             |             |             |             |             |
| 531 01 98-66 | F           |             |             |             |             |             |             |
| 531 01 98-68 | E           |             |             |             |             |             |             |
| 531 01 98-70 | C           |             |             |             |             |             |             |
| 531 01 98-99 | F           |             |             |             |             |             |             |
| 531 01 99-00 | F           |             |             |             |             |             |             |
| 531 01 99-04 | F           |             |             |             |             |             |             |
| 531 01 99-05 | F           |             |             |             |             |             |             |
| 531 01 99-26 | F           |             |             |             |             |             |             |
| 721 61 81-01 | E           |             |             |             |             |             |             |
| 723 12 87-01 | F           |             |             |             |             |             |             |
| 725 23 68-71 | DH          |             |             |             |             |             |             |
| 725 23 70 51 | DH          |             |             |             |             |             |             |
| 725 23 76-51 | C           |             |             |             |             |             |             |
| 725 24 49-51 | ABDEH       |             |             |             |             |             |             |
| 725 24 61-51 | GH          |             |             |             |             |             |             |
| 725 24 71-51 | E           |             |             |             |             |             |             |
| 725 24 91-71 | E           |             |             |             |             |             |             |
| 725 24 93-71 | E           |             |             |             |             |             |             |
| 725 24 95-51 | C           |             |             |             |             |             |             |
| 725 24 97-51 | CH          |             |             |             |             |             |             |
| 725 24 99-51 | C           |             |             |             |             |             |             |
| 725 25 15-51 | E           |             |             |             |             |             |             |
| 725 53 25-01 | F           |             |             |             |             |             |             |
| 725 53 76-55 | C           |             |             |             |             |             |             |
| 725 54 93-01 | C           |             |             |             |             |             |             |
| 725 63 27-51 | H           |             |             |             |             |             |             |
| 725 64 93-51 | ABD         |             |             |             |             |             |             |
| 731 23 22-01 | CE          |             |             |             |             |             |             |
| 732 21 18-01 | EFH         |             |             |             |             |             |             |
| 732 25 10-01 | F           |             |             |             |             |             |             |
| 732 25 16-01 | ACDEH       |             |             |             |             |             |             |
| 732 25 20-01 | CEH         |             |             |             |             |             |             |
| 732 25 22-01 | CFH         |             |             |             |             |             |             |
| 734 11 51-71 | CH          |             |             |             |             |             |             |
| 734 11 62 71 | DEH         |             |             |             |             |             |             |
| 734 11 71-71 | EH          |             |             |             |             |             |             |
| 734 11 77-71 | ACFH        |             |             |             |             |             |             |
| 734 11 85-71 | A           |             |             |             |             |             |             |
| 734 18 23-51 | DE          |             |             |             |             |             |             |
| 735 31 19-00 | D           |             |             |             |             |             |             |
| 735 31 22-00 | D           |             |             |             |             |             |             |
| 735 31 37-10 | D           |             |             |             |             |             |             |
| 735 31 40-10 | BD          |             |             |             |             |             |             |
| 738 21 04-04 | D           |             |             |             |             |             |             |
| 738 21 05-04 | BD          |             |             |             |             |             |             |
| 738 21 06-04 | A           |             |             |             |             |             |             |
| 738 22 03-19 | D           |             |             |             |             |             |             |
| 740 42 22-00 | D           |             |             |             |             |             |             |

N = New part  
Neues teil  
Nouvelle piece  
Nueva pieza  
Ny detalj